Product description

DIN rail holder ID001 is intended for mounting on the base plate BD001.

Safety instructions

Read and follow safety instructions of each modules, which are mounted on the base plate BD001.


Figure 1. External view of DIN rail holder ID001

M3x6
2 pcs.
included in
a package.

1. The DIN rail holder can be mounted on the left side in the first position

2. The DIN rail holder can be mounted below on the base plate

*Figure 2. Mounting positions of the DIN rail holder on the base plate BD001*

Vers. 1.01

This product complies with the relevant clauses of the European Directive 2002/96/EC. The unit must be recycled or discarded according to applicable local and national regulations.

Equipment intended for indoor usage only.

This product is in accordance to following norms of EU: safety norm EN IEC62368-1, RoHS norm EN50581.

Figure 3.1 Lift the fixing arm

3.6 mm

M3x8
2 pcs.
included in
a package.

Figure 3.2 Set the fixing screws

DC adapter
included in
a package.

Figure 3.3 Insert DC adapter and place GS308

Figure 3.4 Pull down and fix the fixing arm

Figure 3. Mounting of the ethernet switch NeTGear GS308 on ID001

M4x8
2 pcs.
included in
a package.

M4x12
2 pcs.
included in
a package.

*Figure 4.1 SRM522 can be mounted on the left side of ID001*

Figure 4.2 SRM522 can be mounted on the right side of ID001

Figure 4. Mounting of the SRM522 series dSCR multiswitch